ALPS 27 VOLUME SET (100kΩ A curve, shaft length : 20mm)

OP-8600VR

* A small PCB for TU-8600/TU-8600R included




[Contents]

- AI PS 27 volume (100k Ω : A curve, shaft length: 20mm)
- PCB for TU-8600/TU-8600R
- 3x6mm binding screw
- * NOTE Although the stock volume included in TU-8600/TU-8600R is $50k\Omega$, this $100k\Omega$ of ALPS 27 volume can be used for TU-8600/TU-8600R without a problem.

● Mount the volume with PCB to TU-8600/TU-8600R as below.



Remove the currently mounted volume pot with PCB from TÚ-8600/TU-8600R.



Solder ALPS27 volume pot and the 6-pin header to the attached PCB, and fix the 2 long spacers combined previously with the attached binding screws as above.



In order to connect the volume shaft with the chassis ground, trim the chassis paint of the chassis surface and fix the volume with the nut. Without this process, a hum noise occurs when you touch the volume knob.

unit to the chassis.

- 6-pin header

Remove the spacers from the PCB, and

Mount the volume unit to the main PCB of

TU-8600/TU-8600R, and mount the whole

2 long spacers.

combine the long and short spacers to make

[Contents]

- AI PS 27 volume (100k Ω : A curve, shaft length: 20mm)

OP-8600VR

- PCB for TU-8600/TU-8600R

- 6-pin header

- 3x6mm binding screw

* NOTE Although the stock volume included in TU-8600/TU-8600R is $50k\Omega$, this $100k\Omega$ of ALPS 27 volume can be used for TU-8600/TU-8600R without a problem.


ALPS 27 VOLUME SET (100kΩ A curve, shaft length : 20mm)

* A small PCB for TU-8600/TU-8600R included

• Mount the volume with PCB to TU-8600/TU-8600R as below.



Remove the currently mounted volume pot with PCB from TÚ-8600/TU-8600R.



Solder ALPS27 volume pot and the 6-pin header to the attached PCB, and fix the 2 long spacers combined previously with the attached binding screws as above.



Remove the spacers from the PCB, and combine the long and short spacers to make 2 long spacers.



Mount the volume unit to the main PCB of TU-8600/TU-8600R, and mount the whole unit to the chassis.

In order to connect the volume shaft with the chassis ground, trim the chassis paint of the chassis surface and fix the volume with the nut. Without this process, a hum noise occurs when you touch the volume knob.